

FERNOX

MAKES WATER WORK

Powerflow Pump Head Adapter

- Facilitates easy connection of power flushing machines to central heating systems via the body of the circulator pump.
- Particularly useful for condensing boilers with in-built circulators
- Allows for cleaning of secondary heat exchangers without dismantling the boiler
- Easy to use
- Saves time on site
- Compatible with all commonly used circulators



Product Uses

The Fernox Powerflow Pump Head Adapter is designed for easy connection of your power flushing pump to heating system pipe work using commonly found pump bodies as a coupling union.

It enables you to flush every radiator on the circuit and gives full flow-rate flushing directly where you need it.

The Fernox Powerflow Pump Head Adapter also gives the added benefit of being able to clean the secondary heat exchangers on combination boilers by simply turning on the DHW tap to engage the boilers diverter valve.

Fitting Guide

The Fernox Powerflow Pump Head Adapter fits all standard central heating pumps and the majority of combination and system boilers where the pump is built into the boiler casing. The Fernox Pump Head Adapter is supplied with three 'O' rings.

Use 72mm x 5mm (smallest of the three large rings) for:

Grundfos UPS 15-50/60
Circulating Pumps CP/SE range
Myson CP
Pegler Terrier TC5/TC6

Use 74mm x 6mm (middle sized and slightly fatter ring) for:

Wilo Gold

Use 80mm x 5mm (largest ring) for:

DAB

Instructions for use

1. Isolate the electricity supply, close the isolating valves on the system pump and remove the pump head. Put the pump head to one side.
2. Insert the small flat 40mm x 5mm gasket over the central suction port on the PHA. This gasket fits all makes of pump.
3. Select the outer large diameter O-ring that best fits the pump – this will vary depending on the make of pump. Refer to the fitting guide.
4. Using the original fixing screws supplied with the pump, fit the PHA in place of the pump head. (If replacement screws are required most pumps use either M5 or M6 size). The PHA will seal without over tightening using the correct O-ring.
5. Connect your power flushing pump to the PHA. Use only PLASTIC (PP) 3/4" female nut liner and seals, as provided with the Fernox Powerflow pump and PHA. Secure these to the hoses with screw clamps. The use of metal connectors will damage the thread on the PHA fittings and reduce its service life. Note that the kidney shaped port on the PHA is the flow to the system and is marked 'F'; whilst the central port with the sprung sliding bush is the system return and marked 'R'.

Care and Maintenance

The Fernox Powerflow Pump Head Adapter is made from rugged, acid resistant polypropylene and stainless steel and requires only minimal maintenance.

The sliding bush should be cleaned and lubricated with silicone oil or silicone grease as required. Check before use that the bush will spring in and out. O-rings may wear or be lost and may require periodic replacement. A replacement O-ring pack is available.